



203903

Kit tubazioni freno anteriore HD XR 1200
HD XR 1200 Front brake line kit



KIT EQUIPMENT

- 1 Braided hose 800 mm.
- 1 Braided hose 850 mm.
- 3 Banjo 45°
- 1 Banjo 90°
- 1 Adapter
- 7 Copper washer
- 1 Banjo bolt

Installation time : 60 minute

Tool requirement :1) Pliers

2) 11-12-14-17 open/box end wrench

3) Loctite 243

4) Torque wrenches

Free Spirits Genuine Parts to be fitted by trained technician only



1



2

Smontare la tubazione dalla pompa freno.
Remove banjo bolt to disconnect fluid line from master cylinder.



3

Smontare le tubazioni dalle pinze freno.
Remove banjo bolt to disconnect fluid line from caliper.



4

Rimuovere il deviatore.
Remove tee brake.



5

Montare l'adattatore (serraggio 20 Nm).
Tighten to 20 Nm adaptor on master cylinder.



6

Preparare le tubazioni applicando del frenafili medio.
Prepare the brake line by applying medium threadlocker.

7



Avvitare ma non fissare i componenti come da foto.
Tighten but do not fix the components as photo.

8



Fissare gli occhielli di raccordo (serraggio 10Nm).
Tighten banjo to 10Nm.



9

Fissare la tubazioni alle pinze freno (serraggio 22/27Nm).
Tighten banjo bolt to 22-27 Nm.



10

Fissare la tubazioni alle pinze freno (serraggio 22/27Nm).
Tighten banjo bolt to 22-27 Nm.



11

Fissare la tubazioni alla pompa freno (serraggio 22/27Nm).
Tighten banjo bolt to 22-27 Nm.

XR 1200 Front Brake Line

standard handlebar

code 203903

