



203904

Tubazioni freno anteriore HD XR1200 con kit 202402-202403
Braided brake line front HD XR1200 with kit 202402-202403



KIT EQUIPMENT

- 1 Braided hose 750 mm.
- 1 Braided hose 625 mm.
- 3 Banjo 45°
- 1 Banjo 0°
- 1 Adapter
- 7 Copper whasher
- 1 Banjo bolt

Installation time : 60 minute

Tool requirement :1) Pliers

- 2) 11-12-14-17 open/box end wrench
- 3) Loctite 243
- 4) Torque wrenches

Free Spirits Genuine Parts to be fitted by trained technician only

1



2



Smontare la tubazione dalla pompa freno.
Remove banjo bolt to disconnect fluid line from master cylinder.



3

Smontare le tubazioni dalle pinze freno.

Remove banjo bolt to disconnect fluid line from caliper.



4

Rimuovere il deviatore.

Remove tee brake.



5

Montare l'adattatore (serraggio 20 Nm).
Tighten to 20 Nm adaptor on master cylinder.



6

Preparare le tubazioni applicando del frenafiletto medio.
Prepare the brake line by applying medium threadlocker.



7

Avvitare ma non fissare i componenti come da foto.
Tighten but do not fix the components as photo.



8

Fissare gli occhielli di raccordo (serraggio 10Nm).
Tighten banjo to 10Nm.



9

Fissare la tubazioni alle pinze freno (serraggio 22/27Nm).
Tighten banjo bolt to 22-27 Nm.



10

Fissare la tubazioni alle pinze freno (serraggio 22/27Nm).
Tighten banjo bolt to 22-27 Nm.



11

Fissare la tubazioni alla pompa freno (serraggio 22/27Nm).
Tighten banjo bolt to 22-27 Nm.

XR 1200 Front Brake Line

race clip on bar code 203903

