



## Custom Dynamics® Quick Disconnect Tour Pak® Wiring Harness Installation Instructions

We thank you for purchasing the Custom Dynamics® Quick Disconnect Tour Pak® Wiring Harness! Our products utilize the latest technology and high quality components to ensure you the most reliable service. We offer one of the best warranty programs in the industry and we back our products with excellent customer support, if you have questions before or during installation of this product please call Custom Dynamics® at 1(800) 382-1388.

**Part Number:** CD-TP-QD-14-HW

**Package Contents:**

- Quick Disconnect Tour Pak® Wiring Harness (1)
- Instructions (1)

**Fitment:** CD-TP-QD-14, CD-TP-QD-SS614 or CD-TP-QD-HD14



Please read all information below before installation

**Warning:** Disconnect negative battery cable from battery; refer to owner's manual. Failure to do so may result in electrical shock, injury, or fire. Secure negative battery cable away from positive side of battery and all other positive voltage sources on vehicle.

**Important:** Motorcycle should be secured on a level surface for installation.

**Important:** This product is designed to be used specifically with the Harley-Davidson® brand Tour-Pak wiring harness.

**Installation:**

1. Secure motorcycle on level surface. Remove seat. Disconnect negative battery cable from the battery.
2. Locate and unplug the rear lighting harness connector to the rear fender from the main wiring harness.
3. Plug the Quick Disconnect Tour-Pak Wiring Harness CD-TP-QD-14-HW into the CD-TP-QD-SS614 (Not Included) or CD-TP-QD-HD14 (Not Included).
4. Route the Quick Disconnect Tour-Pak Wiring Harness CD-TP-QD-14-HW into the Tour Pak®.
5. Connect the wires from the CD-TP-QD-14-HW wiring harness to the Tour Pak® lighting:
  - Black: Ground
  - Red: Brake
  - Blue: Run
  - Purple: Left Turn
  - Brown: Right Turn
  - Orange: Accessory Power
6. Re-connect the battery's negative battery cable to the negative of the battery.
7. Reinstall the seat and ensure the Quick Disconnect Tour-Pak Wiring Harness will not be pinched or damaged under the seat when installed.
8. Check operation of all lighting before riding.

Questions? Call us at: 1 (800) 382-1388 M-TH 8:30AM-5:30PM / FR 9:30AM-5:30PM EST