

## NESS HORN COVER

Fits: 91-12 Big Twins and Sportster  
Part #: 03-590 Chrome, 03-591 Gloss Black

Thank you for purchasing this Arlen Ness product. We believe that our products are the very best available and are engineered to provide a lifetime of use. Basic hand tools and a service manual for your year and model motorcycle are all you need to complete this installation.

Parts:	1- Horn cover
1- 8-32x1/4 button head allen	1- Instructions

Remove OEM horn, cover and bracket assembly.

Remove two bolts holding bracket to horn cover. **Pic 1.** Remove bracket.

Remove two nut plates from OEM cover to reuse in new cover.

Remove horn from cover by removing one hex nut. **Note the orientation of the horn so it can be put in the new cover the same way.**

Install horn into new cover in the same position it was removed. Torque nut to **XX ft lbs. Pic 2**

Install nut plates into new cover. Install mounting bracket to horn and cover using OEM hardware.

Reinstall assembly onto motorcycle. Test horn function.



**Pic 1**

**Remove two bolts**

